



00.33.3.44.02.64.64

Part n°:P145

TING INSTRUCTION

- Remove the original air box.
- Remove the piping which is from the air box to the idling control valve. (See diagram A)
- Connect the small GREEN filter onto the idling control valve.
- Connect the GREEN induction kit to the induction piping and position it so that it does not touch or fool any other engine parts.(see diagram B)

Idling control valve Piping: to remove Original air box Small GREEN filter Original air box GREEN induction kit

IMPORTANT:

The running of your engine is linked directly with the maintenance of the air filter. Clean your air filter every 7000 kms or 4500 miles with Green cleaning products..

WARRANTY:

The air filter guarantee is for defects in materials and workmanship only. Guarantee is void if the air filter is damaged by an accident, unreasonable use, neglect, misuse, abuse, improper installation or other causes not arising out of defects in materials and workmanship. The induction kit is a technical product so it is necessary to have some basic mechanical skills. If problems do not hesitate to have your induction kit fitted by a professional.

Green Technical dept: TEL: 00.33.3.44.02.64.64