



Part n°:P326

FITTING INSTRUCTION

Remove the air box and the air fresh pipe.(see diagram A)

Remove the sealant of the entry of the throttle box.

Fix the green filter with the pipe to the throttle box.(see diagram B)


Fix the small green filter onto the oil vapor pipe with the connector provided.(See diagram B)


Fix the small green filter with the plastic clamp provided. (See diagram B)

Fix the aluminium sheath onto the air inlet nozzle then adjust it towards the green filter. (See diagram B)

Fix the aluminium sheath with the plastic clamps provided.

Adjust the filter so that it does not touch a mechanical part.





IMPORTANT:

The running of your engine is linked directly with the maintenance of the air filter. Clean your air filter every 7000 kms or 4500 miles with Green cleaning products.

WARRANTY:

The air filter guarantee is for defects in materials and workmanship only. Guarantee is void if the air filter is damaged by an accident, unreasonable use, neglect, misuse, abuse, improper installation or other causes not arising out of defects in materials and workmanship. The induction kit is a technical product so it is necessary to have some basic mechanical skills. If problems do not hesitate to have your induction kit fitted by a professional.

Green Technical dept: TEL: 00.33.3.44.02.64.64